

Aventa 3

Machine and User preferences file location

Windows XP

Machine preferences

C:\Documents and Settings\All Users\Application Data\ReSound\Aventa\Machine.pref

User Preferences

C:\Documents and Settings\<user name>\Application Data\ReSound\Aventa\User.pref

Windows Vista / 7 / 8 / 10

Machine preferences

C:\ProgramData\ReSound\Aventa\Machine.pref

User preferences

C:\Users\<user name>\AppData\Roaming\ReSound\Aventa\User.pref